SWISS+TECH®

First in Key Ring Products™



and Utili Key® are registered trademarks, Micro-Tech®, Micro-Plus®, Screwz-All®, Micro-Pac® and First in Key Ring Products" are trademarks of Crestwood Partners, LLC. @2004 Crestwood Partners, LLC

Limited LIFETIME Warranty

Your SWISS+TECH® product is warranted for the life of the user against any defects in material or workmanship.

Abuse, battery expiration, surface coatings which are subject to normal wear and elements, are excluded from the warranty. Simply return your SWISS+TECH® product

> postpaid and insured to: SWISS+TECH Products 701 Beta Drive, Unit 5 Mayfeild Village, Ohio 44143

> > Made in China

Information call: 800,414,8799 or visit at www.swisstechtools.com

Utili • Kev® 6-in-1



5. Serrated Knife Blade

Positions for tool use:

Open position for

#1 Flat Screwdriver.

Micro Eyeglass

Screwdriver.

Bottle Opener.

#1 Phillips

Screwdriver

Open position for

Serrated & Straight

Knife Blades

and Unlock: Locked position Position the Utili-Key® away from you and carefully open by pulling the tips




CAUTION:



Micro • Tech™ 6-in-1

Many Finishes and Materials are available. 4. Sheet Shear These instructions 5. #1 Phillips Screwdriver apply to all.



open and unlock.

Micro • Plus™ 8-in-1

Positions for tool use:

Precision Pliers. Wire Cutter. #2 Flat Wire Stripper

2 Wire Cutter

3. Wire Stripper

4. Sheet Shear

5. #2 Flat

Screwdriver

Sheet Shear

Screwdriver

1 Precision Pliers

BONUS!

1/8" Rule

Markings

6. #2 Phillips Screwdriver

> #2 Phillips Screwdriver









Screwz • All™ 4-in-1

Many Finishes and Materials are available. These instructions apply to all.

3. #2 Phillips Screwdriver
4. #2 Flat Screwdriver
5 Crewdriver

4. #2 Flat Screwdriver
5 Crewdriver

1. #1 Flat

Screwdriver

Micro • Pac™



For full instructions see individual Utili • Key® & Micro • Light panels.

Unlocking Instructions:

Squeeze wire key ring to separate ends and remove from Screw • All* sockets.



for extra torque.

Holding Screwz-All*
for extra torque.

CAUTION:

BONUS!

1/8" Rule

Markings

Utili-Key® features a razor sharp knife blade designed for all types of cutting. Care should be taken to ensure that the cutting edge is always positioned away from the user.



To Open and Unlock: Position the Utili-Key® away from you and carefully open by pulling the tips apart as shown.

Micro • Light



Micro-Light 100,000+ Power Light Hours

The Bright

Light Key Ring
Companion
2.
The perfect
accessory for
all other

- Squeeze ON/OFF
- Continuous
 ON/OFF
 Holds two 3-volt
- lithium batteries
 Replaceable, bright white 100,000+

rs hour LED bulb How To Remove The Cover:

- Place the Micro-Light on a solid, flat surface.
 Using a #1 Phillips driver, turn the four screws on the cover counterclockwise to remove.
- SWISS+TECH® 3. Place the loose screws
- keyring products in a safe place.
 4. Gently pull the cover up to expose the batteries and LED bulb.

- How To Replace The Batteries and LED Bulb:
- 1. Gently pull the batteries up and out of the Micro-Light base. The LED bulb will also come out.

 4. Place straight bulb lead underneath lower battery. Place angled lead on top of upper battery.
- 2. Remove the two batteries. 5. Put and
- 3. Replace with new CR2016 batteries or equivilent 3-volt batteries. Stack the new batteries on top of each other positive (+) side up.
- of upper battery.

 5. Put new batteries and bulb back into case.

6. Replace cover and

align screw holes.

7. Using a #1 Phillips driver, turn the four screws clockwise. Gently tighten.

SWISS+TECH®First in Key Ring Products™

Visit Our Website at www.swisstechtools.com